

CELLPHONESANDBOX

Manual 01 - Battery Cover

Written By: James Linder



Step 1 — Removal 1 - Battery Cover



- In the next few steps, you'll be opening the Kindle by freeing the clips marked in Picture 2.

Step 2



- Picture 1: Insert the blue pry tool directly under the charging port.
- Picture 2: Slide the blue pry tool slightly left, under the headset jack.
- Picture 3: Pry the battery cover open just enough to insert a guitar pick left of the headset jack.

Step 3



- Picture 1: Slide the blue pry tool right, under the power button.
- Picture 2: Pry the battery cover open just enough to insert a guitar pick right of the power button.

Step 4



- Pry from the bottom of the Kindle to the top to release the battery cover clips.
- Pry up the other side.

Step 5



- With the Kindle upside down (charging port at top), use your hands to separate the battery cover from the Kindle. Start at the charging port and work your way down.
- Place battery cover in ZONE V.

Step 6 — Replacement 1 - Battery Cover



- From ZONE V, secure the battery cover to the Kindle.
- Start with the two tabs on either side of the charging port.

Step 7



- Push the bottom into place and work your way to the top.

Step 8



- Power up the device and test the replacement part or parts.